



## CHARGING: ROLLS BATTERY AGM MODELS

ROLLS BATTERY - AGM		0°C (32°F)	10°C (50°F)	20°C (68°F)	25°C (77°F)	30°C (86°F)	40°C (104°F)
2V	CHARGE VOLTAGE	2.55 V	2.51 V	2.48 V	<b>2.45 V</b>	2.42 V	2.39 V
	FLOAT VOLTAGE	2.40 V	2.36 V	2.32 V	<b>2.30 V</b>	2.28 V	2.24 V
12V	CHARGE VOLTAGE	15.30 V	15.06 V	14.84 V	<b>14.70 V</b>	14.55 V	14.34 V
	FLOAT VOLTAGE	14.40 V	14.16 V	13.94 V	<b>13.80 V</b>	13.65 V	13.44 V
24V	CHARGE VOLTAGE	30.60 V	30.12 V	29.69 V	<b>29.40 V</b>	29.11 V	28.68 V
	FLOAT VOLTAGE	28.80 V	28.32 V	27.89 V	<b>27.60 V</b>	27.31 V	26.88 V
48V	CHARGE VOLTAGE	61.20 V	60.24 V	59.38 V	<b>58.80 V</b>	58.22 V	57.36 V
	FLOAT VOLTAGE	57.60 V	56.64 V	55.78 V	<b>55.20 V</b>	54.62 V	53.76 V

Use highlighted values when charge equipment is supplied with temperature compensation at 5mv/°C/Cell. Sensor should be mounted directly to side of cell casing below electrolyte level to determine accurate cell temperature. Note: remove cover and mount directly to cell on dual-container models. If temperature compensation is not available, voltage settings should be monitored and adjusted based on actual cell temperature.